

INTCON

Естественная конвекция Hottherm

	Температура горячего теплоносителя, С	Тепловая мощность, Вт	Расход горячего теплоносителя, л/ч
Hottherm 1000	75/65/20	284	30
	70/60/20	240	26
	65/55/20	196	21
	60/50/20	160	18
	55/45/20	125	14
	50/40/20	95	11
	45/35/20	65	7
Hottherm 1250	75/65/20	356	38
	70/60/20	302	31
	65/55/20	247	25
	60/50/20	202	21
	55/45/20	156	18
	50/40/20	121	13
	45/35/20	87	9
Hottherm 1450	75/65/20	473	47
	70/60/20	401	41
	65/55/20	328	36
	60/50/20	268	29
	55/45/20	207	22
	50/40/20	162	18
	45/35/20	118	14
Hottherm 1750	75/65/20	618	62
	70/60/20	514	52
	65/55/20	410	43
	60/50/20	335	35
	55/45/20	261	27
	50/40/20	202	22
	45/35/20	143	17
Hottherm 1950	75/65/20	767	76
	70/60/20	630	62
	65/55/20	493	48
	60/50/20	403	41
	55/45/20	313	34
	50/40/20	241	26
	45/35/20	168	19